

Ailunce HD1 latest firmware Version V1.54, Software Version V2.08

Issues resolved by this update

1. Add DTMF Keyboard Dialing.

Number 0-9 -> DTMF dial number 0-9.

Menu -> A

Up -> B

Down -> C

Exit -> D

*Scan -> E

#Lock-> F

Press PTT and then dial your DTMF number.



2. The talk permit tone wont plays before the repeater fail tone when HD1 transmit to a repeater.

3. Resolved the problem When switch time slot on VFO B the display won't refresh.

4. Resolved the problem when set analog channel CTCSS to D432N, the setting is not memorialized and go back to D023N.

5. When close the radio and power on again in channel mode scanning, resolved the set backlight will change to always.

6. Resolved the problem when main channel is DMR repeater, sub channel is a analog simplex channel, radio will not receive signals from time to time.

7. Adjust scanning speed.

8. Resolved the problem after using 'Save as', the new filename does not become active.

9. Adjust the speed switch zone via side key.

10. Resolved the problem when transmit to a repeater, needs to press PTT more times.

11. Adjust Rx group lists settings.

Users can follow this tutorial to upgrade the firmware:

<http://www.ailunce.com/blog/upgrade-hd1-firmware.html>